



DOOR OPENER ROMALI

FOR TACTICAL USE IN CONJUNCTION WITH
HOOK AND LINE SETS

RUGGED AND HANDY

The Romali door opener is used for opening doors in tactical operations in conjunction with hook and line sets. Despite its low weight and compact dimensions, it is very rugged. The accompanying transport bag made of strong, durable fabric is suitable for uncomplicated attachment to Molle carrying systems.

FLEXIBLE IN USE

The EOD tool developed by ELP GmbH can be used with almost all doors that open in the direction of travel. Commercially available fire doors with flame protection lips are no problem for this door opener. Especially in tactical operations using hook and line sets, this door opener is very efficient.

EASY OPERATION FROM A SAFE DISTANCE

The Romali electric strike is pushed into the door rebate of the door frame by means of a fastening latch on the floor. Once it is securely positioned, a release cord is passed through the release bolt. By removing the safety ring, the electric strike is ready for use. Only now can the release bolt be removed by pulling the release cord - this unlocks the gas pressure damper and the opening plunger extends.



PROPERTIES:

- Low weight (520 g without bag/720 g with bag)
- Highly mobile and rugged
- Intuitive handling
- Operating from a safe distance
- Directly ready for use
- particularly effective in combination with hook and line sets